



Installation, Operation & Maintenance Instructions

Manual Handle Spring Return Units

FOR USE WITH THE FOLLOWING MODELS:


- 03++0*0 – 1006
- 05++0*0 – 1006
- 07++0*0 – 1006

KEY: ++ Will be one of the following:

- 4 - = Male Drive
- 3F = Female Drive
- 7 - = American Male Drive
- 7F = ANSI Female Drive
- 3S = Serrated Female Drive
- 7S = ANSI Serrated Female Drive

*Will be one of the following:

- 2 = Clockwise spring action
- 3 = Anticlockwise spring action




1.) INSTALLATION



- 1.1) Fit unit to bracket/valve with coupling to valve stem (unless a female drive version is used which can be directly connected to valve).
- 1.2) Ensure that coupling (if fitted) can be moved without much effort, such that it does not side load valve stem or manual handle shaft.
- 1.3) Refer to Kinetrol TD111 for recommended screw tightening torques.
- 1.4) Ensure that the handle is fitted in the orientation which allows the safe operation from a stable operating position.
- 1.5) If serrated drive is used – use a Kinetrol insert to ensure drive to valve.

2.) OPERATION

- 2.1) Operating conditions:
 - Angle of travel 90° (Non-Adjustable)
 - Max vibrating conditions: 4g@100Hz
 - Ambient temperature range:-40°C to 80°C
- 2.2) Ensure that the handle is operated whilst standing in a stable position.



Coupling For Male Drive (as supplied with unit)



Typical Serrated Inserts

- 2.3) Rotate handle slowly with a good grip and ensure that there is nothing in the path of an accidentally released lever.
- 2.4) DO NOT allow the handle to be released from the hand grip. Slowly and deliberately rotate the handle against the spring. Note: Releasing the handle whilst in the operating position may damage the device.

3) MAINTENANCE

- 3.1) This manual spring handle does not contain user serviceable components, if the unit is faulty it should be disposed of safely and replaced with a new unit or returned to Kinetrol for repair.
- 3.2) If the output torque is too high for application, then some sizes can be re-tensioned. TD 126 describes the procedure for safely achieving a change in torque.

KF 533

Issue A

C.S.
18/01/10

KINETROL

Trading Estate Farnham Surrey England

Doc. No. TD 160
Page 1 of 1