



1. CONTENTS.

6

6

6

7 7

8

8

8

9

Page. Section.

- 1 1. Contents.
- 2 2. Safety Requirements.
- 3. Installation 3.1 Mounting of Direct Mounting Units onto Kinetrol Positioner-Type Actuators.
 3.2 Mounting of Discrete Positioner.
 3.3 Air and Electrical Connections.
- 5 4. Schematic Functional Diagram.
 - 5. Set-up Diagram and General.
 - 5.1 Setting Travel Speed.
 - 5.2 Setting Limit Switch Cams (Optional Equipment).
 - 5.3 Overview Electronic Settings.
 - 5.4 Default Settings and Reset Procedure.
 - 5.5 Entering and Leaving Setup Mode.
 - 5.6 Automatic Endstop Finding Procedure.
 - 5.7 Proportional Gain and Damping Settings (for Smoothness and Sensitivity).
 - 5.8 Low Current Point and High Current Point Settings.
- 10 5.9 Reversing Clockwise / Anticlockwise Sense of the Positioner.
- 10 5.10 Changing the Direction of Movement on Loss of Signal.
- 11 5.11 Resetting the Feedback Pot.
- 11 5.12 EEPROM Checksum Error.
- 12 5.13 Selecting and Setting Up Non-Linear Curves.
- 13 5.14 Setting Optional Angle Retransmit Span.
- 13 5.15 Adjustment of Position of Optional Clearcone Monitor.
- 14 6. Maintenance & Troubleshooting.
- 14 7. Identity Label.
- **15-22** 8. Baseefa EC Type Examination Certificate & IECEx Certificate of Conformity.
- 23-25 9.1 Spare Parts : Exploded View. 9.2 Spare Part Numbers.

(KF 536)



Trading Estate Farnham Surrey England

Doc. No. TD 120 Page 1 of 25



2. SAFETY REQUIREMENTS

2.1 Certification

This instruction document is for special versions of Kinetrol's EL electro pneumatic positioner which are certified for use in areas with a risk of explosion. The unit is approved by Baseefa as intrinsically safe (IS) to the European classification Ex ia IIC T4 Ga in accordance with ATEX directive 2014/34/EC allowing it to be used in non mining Zone 0 areas, provided it is installed according to approved procedures – see relevant pages of EC-Type Examination Certificate No. Baseefa03ATEX0098X – issue 3 reproduced on pages 15-18 of this document, and Harmonised European Standard EN 60079-0:2012 + A11:2013 and EN 60079-11:2012. The unit is also approved to equivalent IECEx standards as shown reproduced on pages 19-22 of this document.

2.2 Barrier

The unit is powered by compressed air and positioning is controlled by a 4-20mA signal. The angle retransmit option is also loop powered, requiring 8 to 24 volts to drive the 4-20mA current through it. In hazardous area applications, electrical sources for both circuits must be located outside the hazardous area and the currents passed through two <u>separate</u> approved 28v 300 ohm shunt zener diode barrier devices as defined on page 16 of these instructions. These will act to prevent dangerous levels of electrical energy being available inside the hazardous area.

Without approved 28v 300 ohm barriers, the positioner is not safe in a hazardous area.

2.3 Identification

IS approved positioners are identified by a black anodised aluminium label attached to the lid. This is reproduced as Figure 10 on page 14 of this document. Non-IS versions carry a red label.

Do not use positioners with red labels in hazardous areas.

2.4 Limit Switches and Proximity Sensors

If the unit is fitted with the limit switch option, each limit switch must also be connected via a suitable barrier. This could make in total up to four possible circuits, each of which must be electrically isolated from each other. If proximity sensors are fitted in place of the limit switches, then these again must be connected separately and electrically isolated and wired via a suitable barrier as defined in section 3.3 and on page 16.

Without approved barriers, these switches are not safe in a hazardous area.

2.5 Environment Conditions

The ambient temperature range allowed for use of this equipment is -20°C to 70°C. It is the responsibility of the user to ensure that the environmental conditions are compatible with the materials used in the construction of this device. If in doubt, contact Kinetrol.

2.6 Vibration Resistance

Maximum mounting sinusoidal vibration is 4g at a maximum frequency of 100Hz in any direction.

2.7 Dust Atmosphere

The use of the EL positioner does not extend to dust atmospheres. It is recommended that the unit surface is occasionally wiped clean to prevent dust build up.

2.8 Optional Clearcone Monitor

The fitting of a special version of the clearcone monitor is allowed within the ATEX approval of the positioner. It has an electrically conductive surface which prevents the build up of static electricity. It must be factory fitted with the positioner, although spare parts can be fitted if it becomes damaged.

Issue	C.S.
R	22.06.23

	Latata	Langhama	CUMMON	
raomo	Estate	Farmam	Surrey	Fnolano
i i a an i g			001109	Lingiania

KINETROL



3. INSTALLATION

3.0 Introduction

Positioners can be supplied direct-mounted, or ready to be direct-mounted, onto Kinetrol rotary actuators, or in standalone (discrete) form for fitting via a mount kit to any 90 degree rotary actuator. If the positioner is supplied ready mounted on an actuator, sections 3.1 and 3.2 can be bypassed. Positioner-type Kinetrol actuators (ready for direct mounting of positioners) are available in models 03 to 15 inclusive.

These instructions cover the possible use of both metal and moulded feedback coupling. It is expected that most units will contain a moulded coupling.

3.1 Mounting of Direct Mounting Units onto Kinetrol Positioner-Type Actuators



FIGURE 1. Mid Travel Orientation of Actuator Square and Positioner Box.



FIGURE 2. Location of Anti-Backlash Spring on 07 & Larger Squares. (Metal Coupling only)





Doc. No. TD 120

Page 3 of 25

3.1.1 Move actuator vane to mid travel position, with its output square as shown in Figure 1. This is essential to prevent subsequent error in orienting positioner square.

3.1.2 Remove positioner cover, and undo the five M4 slot-headed screws holding the red plastic carrier plate into the body. Disconnect the two wires to the servo valve, and lift out the whole carrier plate assembly complete with shaft and circuit etc.

3.1.3 Bolt the positioner body to the actuator in the orientation shown in Figure 1, taking care that O-rings are in place to seal the ports into the actuator, and that the actuator shaft is centred in its hole.

- 3.1.4 (a) Metal coupling versions on 07 and larger models: fit anti-backlash spring over one corner of the actuator square as shown in Figure 2.
 - (b) Moulded coupling versions: on all direct mount versions, loosen central screw in coupling shaft so that the collet is not closed, and fit coupling over shaft square.

3.1.5 Observe the range of motion available to the positioner shaft, limited by the correct running of the potentiometer quadrant wheel, driven by the stainless steel strap (see Figure 3). Fit the carrier plate/shaft assembly back into the positioner box with the shaft near mid-range, "feeling" the female square in the positioner shaft onto the male actuator square while maintaining its position near mid range. It is essential that the two shafts are correctly oriented relative to each other, since if they are 90 degrees out, the quadrant wheel can be forced too far and damage done to the drive mechanism during subsequent actuator movements. It is possible to fit the positioner correctly with the actuator square at one end of its travel, but experience indicates a high probability of mistaking the direction of movement of the actuator – hence it is strongly advised that the positioner be fitted with the actuator square at the mid-travel position, where there is no ambiguity possible.

Moulded coupling version: Ensure coupling is fully engaged before tightening the central screw (torque to 6 lbf in. to 8lbf in. / 0.7Nm to 0.9 Nm) to close the collet and therefore removing any backlash.

Trading Estate Farnham Surrey England

R-AR7656 / P-AR7650 / N – AR7059 / M – AR6971 / L - AR6419 / K - AR6347 / J-AR6096 / H – AR 6082 / G – AR 5487 / F – AR 5608 / B	E - AR 5293

NETRO

C.S.

22.06.23

Issue



3.2 Mounting of Discrete Positioner

Design and manufacture of the mount kit between positioner and actuator is outside the scope of this document. It is essential that the shaft of the actuator is well aligned with the positioner shaft, and that the two are coupled together with a minimum of backlash – any backlash acts to deteriorate the performance of the positioner/actuator combination.

It is also essential that the 90 degree travel of the actuator moves the positioner shaft through the correct 90 degree range of travel. The easiest way to ensure that this happens is to mount the discrete unit with the lid and indicator in place – set both the actuator and positioner to mid travel, and mate the two in this orientation. Don't take any chances with this, since misorientation of the positioner shaft and consequent movement beyond its designed range of travel will probably result in damage to the positioner pot drive mechanism. With moulded coupling versions, the Namur drive or Kinetrol square option is an insert in the coupling which can be removed by releasing the central screw.

3.3 Air and Electrical Connections.



3.3.1 Air supply.

Connect air supply (pressure between 3.5 and 7 bar, 50 and 100psi.) to the supply port. It is essential that the air is clean, dry and oil-free. Quality class 6.4.4 (according to ISO standard 8573-1:2010) is easily adequate – this implies 5 micron max. particle size, 3°C dew point max., and 5 mg/cubic metre max. oil content. If ambient temperature is lower then 8°C, ensure that the dew point is 5°C lower than the ambient temperature.

Trading Estate Farnham Surrey England

Doc. No. TD 120

Page 4 of 25

3.3.2 DIN Plug Option.

C.S.

22.06.23

Issue

R

The DIN plug option is not available on intrinsically safe positioners.

R-AR 7656 / P-AR7650 / N – AR7059 / M – AR6971 / L - AR6419 / K - AR6347 / J-AR6096 / H – AR 6082 / G – AR 5487 / F – AR 5608 / E - AR 5293

KINETROL



3.3.3 Positioner Signal.

The positioner signal must be 4-20mA. The positioner gives a positioning response between 0 and 90 degrees linearly or nonlinearly related to the signal. The positioner is loop powered – that is the signal itself supplies all the electrical power, and no separate power source is needed. In order to supply enough power, the unit needs between approximately 6 and 8 volts to drive the signal current through it – it behaves electrically like a resistor in series with a zener diode. A typical 4-20mA source with a 24v DC supply is compatible with this input, and can drive a full signal through both a 28v 300 ohm barrier and the positioner with parameters given on page 16.

3.3.4 Angle Retransmit Supply.

The optional angle retransmit circuit is also loop powered, requiring 14 to 24 volts DC to drive the 4-20mA current through it – the current passed is linearly proportional to the actual positioner shaft angle. Like the signal supply, it must also be powered through a separate 28v 300ohm barrier with parameters shown on page 16. The retransmit circuit reads the same angle transducing potentiometer as the positioner circuit – however, the angle retransmit circuit remains functional on loss of positioning signal and/or air supply, and conversely the positioner remains functional, as long as a signal is present, even if the angle retransmit circuit is fitted and there is no supply to energise its loop. Nevertheless, the angle retransmit circuit is electrically isolated from the positioner signal circuit.

3.3.5 Feedback Switches

There are two types of feedback switches that can be fitted, these are:

(a) Two V3 type micro switches with independent adjustable operating strikers. Each switch must be connected to its own barrier – suggested 28v 300 ohm barrier with parameter's shown on page 16.

(b) Two V3 type proximity sensors. These are powered from a nominal 8v source and must be connected independently to a barrier having the following maximum parameter's: Ui = 16v, Ii = 25mA, Pi = 64mW as shown on page 16.

4. SCHEMATIC FUNCTIONAL DIAGRAM.



FIGURE 5. SCHEMATIC FUNCTIONAL DIAGRAM OF DIGITAL EL POSITIONER

lssue R	C.S. 22.06.23	KINETROL	Trading Estate Farnham Surrey England	Doc. No. TD 120 Page 5 of 25



5. SET UP.

5.0 Introduction

When the positioner/actuator combination is installed in its application, set up the control adjustments if necessary. For most applications, it is likely that the factory settings will be satisfactory – the low and high current points are set to give 0-90 degree movement in response to a 4-20mA signal, the flow regulators are set for maximum travel speed, and the proportional gain and damping settings adjusted for a good level of sensitivity and smoothness suitable for most applications. The jumper is set in the "off" position to give a linear characteristic with travel extrapolated beyond the low and high current settings. If you need to change the settings, read the following section carefully.



FIGURE 6a. DIGITAL EL CONTROL ADJUSTMENTS. OPEN BOX, TOP VIEW - MOULDED COUPLING.

5.1 Setting Travel Speed.

Set the travel speed using the exhaust flow adjuster screws (see Figure 4.). This only applies if you want to reduce the speed from its supplied maximum factory setting.

5.2 Setting Limit Switch Cams (Optional Equipment).

Limit switch cams are factory set (if fitted) to give end-of-travel switching with one switch at each end. The two possible types of coupling require slightly different approaches to setting.

5.2.1 Moulded coupling cams, shown in figure 6a, can be adjusted using light pressure to rotate in 1 degree increments. Adjust the lower cam first using a screwdriver to lever against special pegs moulded into the carrier plate or use finger pressure. Secondly move the upper cam using finger pressure only. Graduated marks on the top of the coupling are provided to gauge the position of the actuator with the lid removed. This can be lined up with an arrow marked on the servo valve lid.



FIGURE 6b. DIGITAL EL SWITCH STRIKER METAL COUPLING. OPEN BOX, TOP VIEW.

5.2.2 Metal coupling cams are adjusted by releasing the screw shown in figure 6b, moving to desired position and re tightening. Set the lever cam first. Ensure the clamp section of the cam does not strike a switch at any part in the actuator's travel.

Issue C.S. R 22.06.23	KINETI
--------------------------	--------

Doc. No. TD 120 Page 6 of 25



5. SET UP (Continued)

5.3 Overview – Electronic Settings.

The EL digital positioner circuit can operate to give actuator position accurately proportional to input current, or it can operate as a non-linear device accurately following one of a number of fast open, or slow open, exponential curves. Linear or non-linear, it can easily be calibrated to scale its operating line, or curve, between any two user defined points in its operating range. The positioner circuit is powered entirely from the 4-20mA input signal. It is tuned and calibrated by simple and quick operation of its three push buttons, with red LED (light emitting diode) indication of the selected parameter. The positioner can also calibrate itself automatically to the actuator or valve endstops. The actuator dynamic response can be optimised by simple adjustment of the positioner circuit proportional gain and damping variables. All tuning and calibration data is stored digitally, and is retained in non-volatile memory, so that the positioner powers up with all the same settings it had when last powered down.

The positioner may be operated either as a linear or non-linear device. Non-linear operation is enabled by fitting a jumper link to the positioner with the positioner (and position retransmit if fitted) powered down (i.e. input current at 0 mA). When the positioner is powered up with the link "on" (see figure 6 for its position), it will then operate as a non-linear device for as long as it remains powered up. Conversely, when the positioner is powered up with the link "off", it will operate as a linear device as long as it remains powered up. Changing the link from "on" to "off" or vice-versa while the circuit remains powered up will not cause a change from non-linear to linear operation – the position of the link is only effective during power up.

Whether operating as a linear or non-linear device, the positioner has two distinct modes of operation, Normal Mode and Setup Mode.

In Normal Mode the positioner simply positions its actuator in response to the 4-20mA input signal. When the positioner is powered up, it always starts in Normal Mode. In Normal Mode, the LEDS are not lit. The positioner stays in Normal Mode until Setup Mode is selected manually.

In Setup Mode the positioner can be tuned and calibrated for its application. Although the position is still controlled, it does not always follow the input signal. When tuning and calibration is complete the positioner should always be returned to Normal Mode for continued normal use.

Operating in Setup Mode is described in the following sections.

5.4 Default Settings and Reset Procedure.

The positioner can be reset with a complete set of default values when powered up in any operating mode, by pressing all three push buttons (UP, DOWN and SET) simultaneously. This will overwrite all the existing proportional gain, damping, curve selection and calibration data with default values which are suitable for a typical forward acting linear positioner with mid range values for proportional gain and damping (but not necessarily optimised for a particular application). This procedure is useful in the case where errors in calibration have resulted in positioner behaviour which seems incomprehensible, and it is necessary to return to a predictable basic setup. The positioner should always be tuned and then recalibrated immediately after this resetting process.

C.S. KINETROL

Issue



SET UP (Continued)

5.5 Entering and Leaving Setup Mode.

Setup Mode is selected from Normal Mode by simultaneously pressing the UP and the SET push buttons (i.e. the two outside ones). This causes the LED labelled PGAIN (short for Proportional Gain) to light continuously. In Setup Mode, each of the parameters in the list below may be selected for adjustment by pressing the UP or DOWN push buttons as required. The parameter selected is indicated on the positioner circuit by an LED lighting next to the parameter's name.

PGAIN	-	Proportional Gain
DAMP	-	Damping
CURVE	-	Non-Linear Curve Selection
LOW	-	Low Current Point Calibration
HIGH	-	High Current Point Calibration
POT	-	Feedback Potentiometer Bottom of Range Setting

When the required parameter has been selected for adjustment, the SET push button is pressed to allow adjustments to be made – the LED next to the selected parameter starts to blink, to indicate that Adjust Mode is active. Operation in the Adjust Mode for each parameter is described in the following sub-sections. To leave Adjust Mode, press the SET push button again – this causes the LED to light continuously, and allows movement between parameters again.

Note: There is no Adjust Mode for the feedback potentiometer bottom of range setting, but the automatic end stop finding sequence can be initiated when this parameter is selected.

To leave set up mode (when the adjustments have been made and the SET push button pressed to leave Adjust Mode), press the DOWN push button repeatedly to move down the parameter's and off the end of the list – at this point the LEDs cease to light, and the positioner is back in Normal Mode.

5.6 Automatic Endstop Finding Procedure.

The positioner can automatically calibrate itself to range between any mechanical end stops (either the built-in actuator stops, or any external stops built into the application). During the finding sequence, the positioner moves the actuator up to the top and bottom stops and records their positions. It then uses these positions as the HIGH and LOW positions in the calibration data, and applies the existing values for HIGH and LOW current input. Note that if the positioner was reverse acting before the sequence, it remains so after the sequence.

The End Stop Finding Sequence starts when the POT parameter is selected, and the UP and SET push buttons (i.e. the two outside push buttons) are pressed simultaneously. The POT LED starts to blink, and the actuator moves steadily up scale from its set position. When its movement is stopped by the the top physical end stop, the positioner waits briefly, then moves the actuator steadily downscale until it runs against the bottom physical endstop, where again it waits briefly, and finally moves quickly back to the set position. The calibration data is written to non-volatile memory while the actuator pauses at its bottom stop.

If the positioner is in service on an application where excursions to the end stops will be disruptive, avoid initiating this sequence.

5.7 Proportional Gain and Damping Settings (for Smoothness and Sensitivity).

Select Setup Mode, and the first parameter selected is automatically PGAIN – Proportional Gain. Press the SET push button, and the PGAIN LED will start blinking. The value of the parameter can now be increased or decreased by pressing the UP or DOWN push buttons as required. There are twenty nine (29) PGAIN settings which can be selected, the setting altering by a factor of about 1.1 each time the UP or DOWN button is pressed. The default setting lies in the middle of the range, giving fourteen settings above and fourteen below. Any button presses beyond the last (fourteenth) will have no effect.

Trading Estate Farnham Surrey England

Doc. No. TD 120

Page 8 of 25

Note: As soon as the UP or DOWN push button is pressed, the new PGAIN value is stored in non-volatile memory and is retained even if the positioner is de-energised before leaving Adjust and Setup Modes.

R-AR7656 / P-AR7650 / N – AR7059 / M – AR6971 / L - AR6419 / K - AR6347 / J-AR6096 / H – AR 6082 / G – AR 5487 / F – AR 5608 / E - AR 5293

KINETROL

C.S.

22.06.23

Issue



5.SET UP (Continued)

5.7 Proportional Gain and Damping Settings (for Smoothness and Sensitivity) – continued

The positioner is active while adjusting the PGAIN setting, and continues to follow the input signal. This gives the opportunity to change the input signal in a manner typical of the application, and to observe qualitatively the response of the positioner, and how it has been affected by changing the PGAIN setting, so as to optimise the response. Pressing the UP button maximises the sensitivity and accuracy, at the cost of increased jerkiness of response when the signal is ramped smoothly, and if you go too far this increases the proportional gain so much that the positioner becomes unstable and hunts around the position set by the signal. Pressing the DOWN button maximises smoothness during ramping of the signal, at the cost of losing rapidity of response to small changes in signal. When the right setting has been found, press the SET button again to leave Adjust Mode – the PGAIN LED will now light continuously.

The DAMP (damping) parameter should be set after the PGAIN has been optimised. In Setup Mode select the DAMP parameter (second up from PGAIN) by pressing the UP button until the DAMP LED lights continuously. Press the SET button to select Adjust Mode, and the DAMP LED will blink. Damping can be increased and decreased by pressing the UP or DOWN buttons. There are twenty nine damping settings which can be selected, the setting altering by a factor of 1.1 each time the UP or DOWN pushbutton is pressed. The default setting lies in the middle of the range, giving fourteen settings above and fourteen below. Any button presses beyond the last (fourteenth) setting will have no effect.

Note: As soon as the UP or DOWN button is pressed, the new DAMP value is stored in non-volatile memory, and is retained even if the positioner is de-energised before leaving Adjust and Setup Modes.

The positioner is active while adjusting the DAMP setting, and continues to follow the input signal. This allows the signal to be waggled to optimise the response while still adjusting the DAMP setting. Try stepping the signal suddenly so that the positioner approaches setpoint at full speed having travelled 45 degrees or more, and adjust the DAMP setting to just avoid overshoot here. Try this travelling up and downscale. When the right setting has been found, press the SET button again to leave Adjust Mode – the DAMP LED will now light continuously.

5.8 Low Current Point and High Current Point Settings. (Replaces Zero and Span Adjustment).

The positioner characteristic can be accurately calibrated by setting two points, the Low Current Point (LCP) and the High Current Point (HCP). Each point is defined by a position and an input current. These points can lie anywhere in the range of travel of the actuator, and in the input signal range of 4 to 20 mA. The only other restriction is that the input current at the HCP must exceed the input current at the LCP by at least 5mA. To obtain the best accuracy, it is necessary to select the two points as far apart as possible. In both linear and non-linear operation this allows forward acting, reverse acting, and forward or reverse acting split range characteristics to be implemented. Table 1 below shows some illustrative examples.

Table 1. Various Sets of LCP and HCP Settings



Figure 7. Illustration of LCP and HCP

Low Curr	ent Point	High Curr	ent Point	Description			
Input	Angle	Input	Angle				
Current, mA	Degrees	Current, mA	Degrees				
4	0	20	90	Forward Acting, 100% range			
4	90	20	0	Reverse Acting, 100% range			
4	0	12	90	Split Range Forward Acting, 50% bottom range			
4	90	12	0	Split Range Reverse Acting, 50% bottom range			
12	0	20	90	Split Range Forward Acting, 50% top range			
12	90	20	0	Split Range Reverse Acting, 50% top range			
4	0	20	45	Forward Acting, 200% range			
4	45	20	0	Reverse Acting, 200% range			
I		1 1					
sue C.S R 22.06	23		ROIL	Trading Estate Farnham Surrey England	Doc. No. TD 120 Page 9 of 25		



5.SET UP (Continued)

5.8 Low Current Point and High Current Point Settings. (Continued).

To set LCP, select the LOW parameter in Setup Mode by pressing the UP button until the LOW LED lights continuously. Press the SET button to select Adjust Mode, and the LOW LED will blink. Adjust the input signal current within the range 4-20mA to the value you want to define for the Low Current Point – note that changes in input current within the 4-20mA band do not result in positioner movement at this stage – the positioner holds the actuator at the angle where it was before Adjust Mode was selected, irrespective of input current. Press the UP or DOWN buttons to move the positioner to the angle you want to define for the Low Current Point – if you hold the button down continuously, the positioner will traverse the actuator steadily, or if you give short blips it will move approximately 1/40 degree (one fortieth) for each blip, to allow precise edging into exactly the required position. When the actuator is in exactly the position you want, and the signal is adjusted to exactly the value you want (this can be readjusted after the position has been set if you want), press the SET button again to record the signal and position as the Low Current Point, whereupon the actuator will make a small leap and then settle back to the LCP again, the positioner will return to Setup Mode, and the LOW LED will light continuously. The positioner will now respond to its input signal again.

Note: As soon as the SET button is pressed, the LCP position and signal are stored in non-volatile memory, and are retained even if the positioner is de-energised before leaving Setup Mode.

To set HCP, select the HIGH parameter in Setup Mode by pressing the UP button until the HIGH LED lights continuously. Press the SET button to select Adjust Mode, and the HIGH LED will blink. Adjust the input signal current within the range 4-20mA to the value you want to define for the High Current Point – note that changes in input current within the 4-20mA band do not result in positioner movement at this stage – the positioner holds the actuator at the angle where it was before Adjust Mode was selected, irrespective of input current. Press the UP or DOWN buttons to move the positioner to the angle you want to define for the High Current Point – if you hold the button down continuously, the positioner will traverse the actuator steadily, or if you give short blips it will move approximately 1/40 degree (one fortieth) for each blip, to allow precise edging into exactly the required position. When the actuator is in exactly the position you want, and the signal is adjusted to exactly the value you want (this can be readjusted after the position has been set if you want), press the SET button again to record the signal and positioner will return to Setup Mode, and the HIGH LED will light continuously. The positioner will now respond to its input signal again.

Note: As soon as the SET button is pressed, the HCP position and signal are stored in non-volatile memory, and are retained even if the positioner is de-energised before leaving Setup Mode.

5.9 Reversing Clockwise/ Anticlockwise Sense of the Positioner.

Refer to TD 180 for an illustrated version of this procedure.

The LCP and HCP settings described in the previous section can be used with complete success to reverse the sense of the positioner, using settings such as the reverse settings listed in Table 1. However, this will not change the direction of movement on loss of signal – see the next section for how to set this as desired.

5.10 Changing the Direction of Movement on Loss of Signal.

On being de-energised with air supply still fully pressurised (i.e. on disconnection of the signal, or when the signal falls below 3.5mA), the positioner moves the actuator in a direction set by the de-energised position of the servo valve. This direction of movement is independent of the LCP and HCP settings described in the sections above.

Movement on loss of air pressure is unpredictable for double acting positioners – if position needs to be held on loss of pressure, then it is necessary to order an external pressure sensing lockout valve assembly, and if a definite end of travel position is required on loss of pressure, then it is necessary to order a spring return unit.

 Image: State Fail
 Im

Doc. No. TD 120 Page 10 of 25

C.S.

22.06.23

Issue



5.SET UP (Continued)

5.10 Changing the Direction of Movement on Loss of Signal (continued).

On double acting actuators the unit is factory set to move clockwise (as viewed from the positioner lid) on loss of signal.

On spring return actuators the unit is factory set to move in the spring return direction on loss of air, or on loss of both air and signal, but it is set to move clockwise (as viewed from the positioner lid) irrespective of spring direction on loss of signal only.

To change the direction of movement on loss of signal, carry out the following steps:

- (1) Disconnect air supply and signal.
- (2) Undo screw holding down changeover block (see Figure 6).
- (3) Rotate changeover block 90 degrees, taking care to keep rubber gasket lined up with holes in body.
- (4) Re-tighten screw holding down changeover block making sure it remains in alignment with the body.
- (5) Undo outer two angle pot wire terminal screws, swap blue and yellow wires over to reverse sense of pot connection, and re-tighten screws.
- (6) Re-connect air supply and signal, and carry out Resetting Feedback Pot procedure (see next section).

5.11 Resetting the Feedback Pot.

This procedure is necessary only if the pot has been moved from its factory setting, or if the direction of movement on loss of signal has been changed as instructed in the previous section.

The positioner circuit needs the feedback pot to be positioned at the correct angle, such that its wiper reads the right voltage when the actuator is against its downscale endstop – i.e. against the endstop it reaches when the air supply is connected, but the signal is disconnected. The circuit itself can identify this voltage when it is powered up in Setup Mode with the POT parameter selected – when the pot is adjusted correctly, the POT LED changes from lighting continuously to blinking.

To set the pot, first move the actuator to the downscale endstop by connecting the air supply and disconnecting the signal. When it is in this position, hold it there by fitting a keeper plate if the unit has a spring return set to fail against the opposite stop, or by simply disconnecting the air supply if the unit is double acting or has a spring return set to fail against this stop. Reconnect the signal, and set to any current between 4 and 20mA. Select Setup Mode, and press the UP button until the POT LED lights continuously. Unclamp the pot clamp screws, taking care not to unscrew them too far such that they disengage from the nuts in the carrier plate. Rotate the pot until the POT LED changes from continuous to blinking illumination. Re-tighten the clamp screws, and reconnect the air supply. If the unit needed a keeper plate, drive it downscale by disconnecting the signal, and then remove the keeper plate with the air supply on.

5.12 EEPROM Checksum error

Each time calibration or setting data is written to EEPROM (non-volatile memory) by the positioner circuit, a checksum of all EEPROM data is calculated and written to EEPROM. Hence if there is a power supply (i.e. signal) interruption during the EEPROM write procedure, the checksum will not be written correctly, or at all. After the interruption, during its initialisation routines the positioner carries out a checksum calculation of the data stored in EEPROM. If the newly calculated checksum and the stored checksum are not identical, the positioner enters an error routine, and does not start Normal Mode operation. This condition is indicated by the LEDs lighting one after the other in sequence. If this condition is achieved, carry out the reset procedure described in section 5.3, and then recalibrate as detailed in sections 5.5 to 5.8.

Issue C.S. R 22.06.23

Trading Estate Farnham Surrey England

Doc. No. TD 120 Page 11 of 25

KINETROL



5. SETUP (continued).

5.13 Selecting and Setting Up Non-Linear Curves.



Figure 8. Plots of the Non-Linear Curves

The positioner may be operated either as a linear or non-linear device. Non-linear operation is enabled by fitting a jumper link to the positioner with the positioner (and position retransmit if fitted) powered down (i.e. input current at 0 mA). When the positioner is powered up with the link "on" (see figure 6 for its position), it will then operate as a non-linear device for as long as it remains powered up. Conversely, when the positioner is powered up with the link "off", it will operate as a linear device as long as it remains powered up. Changing the link from "on" to "off" or vice-versa while the circuit remains powered up will not cause a change from non-linear to linear operation – the position of the link is only effective during power up.

When the positioner is powered up with the jumper link "on" and the air supply connected, then any one of eleven characteristic curves may be selected. Press the SET button to go into Setup Mode, and select the CURVE variable by pressing the UP button until the CURVE LED lights continuously. It is easiest to select the required curve from the eleven available by setting the input signal current to midway between the LCP and HCP signal current values – for instance, if the LCP is 4 mA and the HCP is 20 mA, then set the input current to 12 mA for this purpose.

With the signal set at midway between LCP and HCP values, select Adjust Mode by pressing the SET button, and the CURVE LED will now blink. The default curve is in fact the linear curve midway between the other non-linear curves (see Figure 8). To select one of the other curves, press the UP or the DOWN button, and observe the movement of the positioner as its position conforms to the intersection of the mid value signal with the different curves selected from those defined in Figure 8. Each button press steps from one curve to the next one, until at the last curve further button presses have no effect. When the desired curve has been selected, press the SET button to return to Setup Mode.

Note: As soon as the UP or DOWN button has been pressed to select a particular curve, the new curve selection is stored in non-volatile memory and is retained even if the positioner is de-energised before leaving Adjust and Setup Modes.

Each curve is scaled between the two calibration points LCP and HCP. If input currents are reduced below LCP current or increased above HCP current, the positioner stops dead at the LCP or HCP position respectively. This is in fact the difference between the linear curve selected as the default "non-linear" curve, and the linear curve selected when the positioner is powered up with the jumper "off" - the latter gives positions extrapolated on the the same linear characteristic beyond the LCP and HCP signals, whereas the former stops dead at the LCP and HCP positions.

Trading Estate Farnham Surrey England

Doc. No. TD 120

Page 12 of 25

C.S.

22.06.23

Issue

R

NETROL



5. SETUP (continued).

5.14 Setting Optional Angle Retransmit Span and Zero Adjustments.

The angle retransmit circuit is mounted directly underneath the positioner circuit, and its ZERO and SPAN preset pots are accessible using a small instrument screwdriver through the two access holes in the positioner circuit (see Figure 6). Connect the air supply, positioner signal and angle retransmit reader supply. To set the ZERO, move the positioner to its minimum signal position (usually 4mA), and set the ZERO preset pot to give the desired retransmit current. Then set the SPAN by moving the positioner to its maximum signal position (usually 20mA), and adjusting the SPAN pre-set pot to give the desired retransmit current. Recheck and read just these two settings until both are correct - as the SPAN is adjusted, it has a small effect on the ZERO reading, and vice-versa, so a few readjustments may be necessary.

The angle retransmit circuit is fitted with a jumper, which should be fitted to bridge its two pins if you want the circuit to read 4-20mA over 45 degrees or near, rather than the usual 90 degrees. The range adjustment pot is adjustable to give ranges in between these two values. To gain access to this jumper, it is necessary to remove the whole carrier plate assembly from the positioner - see Section 3.1 for instructions on this.

5.15 Adjustment of Position of Optional Clearcone Monitor.





If your positioner is fitted with a Clearcone position monitor, you may need to adjust its angle to read correctly after you have set up the positioner. The internal O-ring slides to give a coarse setting, and the shell mounting slots give a few degrees of fine adjustment. Please note that a special version of the monitor, which has an electrically conductive surface, is fitted to IS EL positioners.

To adjust the position of the angle scale, first unscrew the two self-tapping stainless mounting screws which hold the transparent outer shell to the lid, and lift off the shell complete with its black mask/pointer moulding. Don't lose the screws or the sealing O-ring which seals round the outside of the shell-lid interface.

If you have reversed the clockwise/anticlockwise sense of the positioner, you may at this stage need to replace the self adhesive angle scale sticker with one marked in the opposite sense. Take care to stick it to the scale cone moulding accurately.

Rotate the scale cone by sliding it round on its internal O-ring against the coupling inside it, which is located on the positioner shaft square. This may take some effort if the O-ring has stuck on. Move it until it is reading as near correctly as you can achieve against the pointer on the mask/pointer moulding, which you should hold in position with the outer shell mounting slots centrally located above the screw holes in the lid. Refit the mounting screws, making sure that the mask moulding and the sealing O-ring are well located in the outer shell moulding. Adjust the pointer position to its final position by rotating the outer shell slots against the mounting screws, taking care to position the screws at equivalent positions in both slots so that the shell remains central relative to the rotating parts inside, then tighten the screws to clamp it into position.

Trading Estate Farnham Surrey England

Doc. No. TD 120

Page 13 of 25

lssue	C.S.	177
R	22.06.23	<u> 117</u>

Issue

ETROL

R-AR7656 / P-AR7650 / N - AR7059 / M - AR6971 / L - AR6419 / K - AR6347 / J-AR6096 / H - AR 6082 / G - AR 5487 / F - AR 5608 / E - AR 5293



6. MAINTENANCE AND TROUBLESHOOTING

The EL positioner is designed to be maintenance free during a long life, if it is supplied with clean, dry oil free air, and electrical signals free of noise and high voltage spikes.

When the lid is removed, take care not to wipe all grease from shaft lip seal.

Table 2 is a troubleshooting guide, which aims to assist only with simple easily remedied problems. If problems persist, contact Kinetrol or a Kinetrol distributor for further assistance.

TABLE 2. Troubleshooting Guide.

Refer to TD 181 for a visual guide to troubleshooting and part replacement.

Failure to move when signal and air are connected:

- Check air pressure must be above 50psi./3.5 Bar.
- Check signal is connected with correct polarity.
- Check signal is really above 4 mA
- Discrete units is shaft connected in correct orientation? The feedback pot strap may need replacing if orientation is incorrect.
- Has main feedback pot been rotated, or does it need rotating because the unit has been subjected to change in direction of movement on loss of signal? See section 5.11 Resetting Feedback Pot.
- Is air supply clean, dry, and oil free?

Unit moves slower than expected up-scale or downscale:

- Check air pressure above 50psi / 3.5 Bar?
- Check flow adjuster screws has one been screwed in?
- Is air supply clean, dry and oil free? If not there is a possibility that the positioner servo has been damaged.

Movements are too jerky:

- Ensure coupling screw is not too tight (see section 3.1.5)
- Adjust proportional gain to increase smoothness then reset damping and setpoints as instructed in Section 4.

Lack of sensitivity to changes in signal:

- Adjust proportional gain to increase sensitivity – then reset damping, and setpoints as instructed in Section 4.

Set point is overshot when positioner moves rapidly:

- Adjust damping to eliminate overshoot.

7. IDENTITY LABEL

	(INETR(GU9 9NU, UK € 2813 IECE) II 1 G E	Serial No. Model No. EL Electropneumatic Po BAS 13.0117 Baseefa03A Ex ia IIC T4 Ga Ta - 20°C	Year 20 ositioner ATEX0098 TO + 70°C	— NOTE: 'X' NOT INCLUDED WHEN C/	ASE IS ZINC ALLOY.
lssue R	C.S. 22.06.23	KINETROL] Trading	g Estate Farnham Surrey England	Doc. No. TD 120 Page 14 of 25





8. BASEEFA EC - TYPE EXAMINATION CERTIFICATE- Page 2

Certificate Number Baseefa03ATEX0098X Issue 5



Issued 20 November 2019 Page 2 of 4

Schedule

13

Certificate Number Baseefa03ATEX0098X - Issue 5

15 Description of Product

The EL Electropneumatic Positioner is designed to drive a rotary or linear actuator to a position set by a 4 – 20 mA input signal and hold it there until the input signal changes. The enclosure may be zinc alloy or aluminium alloy which introduces a Specific Condition of Use.

The apparatus comprises a microprocessor based digital positioner circuit which controls a servo valve according to the 4-20 mA input signal and an optional angle retransmit circuit which provides a linear 4-20mA feedback signal which is electrically isolated from the positioner signal loop. The circuits are mounted on two PCBs which are located inside the positioner enclosure together with the position feedback potentiometer and the servo valve. There are also two optional limit switches (either micro-switches or Pepperl & Fuchs NJ 2-V3-N Inductive Proximity switches to Certificate No. PTB00ATEX2032X) which form two separate intrinsically safe circuits which are electrically isolated from the input and feedback signals.

External electrical connections are made via separate terminal blocks inside the positioner enclosure.

Input parameters:

Ui	-	28V	Ci	-	0	or	Ui	=	25.2V	Ci	=	0
Ii	-	93.3mA	Li	-	0		Ia	=	100mA	Li	=	0
\mathbf{P}_i	=	0.653W					$\mathbf{P_i}$	-	0.63W			
Angl	e Ret	transmit circuit:										
Ui	-	28V	Ci	-	0	or	Ui	=	25.2V	Ci	=	0
Ii	-	93.3mA	Li	-	0		Ii	-	100mA	Li	=	0
D.	=	0.653W					P.	-	0.63W			

Limit Switches (micro-switches):

Ui	=	28V	Ci	=	0
Ii	=	93.3mA	Li	==	0
Pi	=	0.653W			

Limit Switches (Pepperl & Fuchs NJ 2-V3-N Inductive Proximity switches to Certificate No. PTB00ATEX2032X)

Ui	=	16V	Ci	=	40nF
Ii	=	25mA	Li	=	50µH
$\mathbf{P}_{\mathbf{i}}$	-	64mW			

16 Report Number

See Certificate History

lssue R

17 Specific Conditions of Use

 The EL Positioner enclosure may be made of aluminium alloy and given a protective epoxy paint finish; however, care should be taken to protect it from impact or abrasion if located in a zone 0 area.

18 Essential Health and Safety Requirements

In addition to the Essential Health and Safety Requirements (EHSRs) covered by the standards listed at item 9, the following are considered relevant to this product, and conformity is demonstrated in the report:

Clause	Subject		
1.2.7	LVD type requirements		
BAS-CERT-081			Tance 1
C.S.		Trading Estate Farnham Surrey England	Doc. No. TD 120
22.06.23			Page 16 of 25



8. BASEEFA EC - TYPE EXAMINATION CERTIFICATE – Page 3

Certificate Number Baseefa03ATEX0098X Issue 5



Issued 20 November 2019 Page 3 of 4

Clause	Subject
1.2.8	Overloading of equipment (protection relays, etc.)
1.4.1	External effects
1.4.2	Aggressive substances, etc.

19 Drawings and Documents

New drawings submitted for this issue of certificate:

Number	Sheet	Issue	Date	Description
91-000-001/A1	1	v	11-11-19	EL Positioner Assembly
91-160/A3	1	М	16-09-19	IS EL Positioner Ex ia IIC T4 ATEX Approved Product Label

Current drawings which remain unaffected by this issue:

Number	Sheet	Issue	Date	Description	
91-000-010/A3	1	D	14-04-03	Angle Retransmit Assembly	
91-000-082/A2	1	D	27-01-06	LS Option Assembly (Proximity Switches)	
91-000-135/A1	1	F	15.09.14	Servo Valve Assembly Mk. 3	
91-000-178/A3	1	G	29.07.13	Coil Assembly	
91-000-185/A2	1	С	21-03-06	LS Option (mechanical switches)	
91-000-191/A2	1	Е	23/11/07	Carrier Plate Assembly Moulded Coupling	
91-000-200/A3	1	С	07-11-11	Wiring Diagram	
91-000-208/A2	1	в	26-01-06	LS Option Assembly (Proximity Sensors)	
91-000-210/A2	1	в	18-01-06	LS Option Assembly (Mechanical Limit Switches)	
91-000-211/212/A2	1	С	23/11/07	05 & 07 Models Carrier Plate Assembly	
91-017-001/A3	1	н	25-11-98	Basic Wound Coil (Low Inductance Variant)	
91-048-001 91-048-002/A3	1	в	05-08-94	Top & Bottom IS Switch Assemblies	
91-048-005 91-048-006/A3	1	В	31-10-07	Top & Bottom LS Switch Assemblies (Micro Switches)	
91-158/A3	1	в	22.08.12	Digital PCB Surface Mount	
91-158-001/A3	1	F	11.09.14	Digital PCB Surface Mount Assembled	
91-159/A3	1	в	22.08.12	Isolated Angle Retransmit PCB Surface Mount	
91-159-001/A3	1	D	11.09.14	Isolated Angle Retransmit Surface Mount	
91-161-001/A4	1	в	27.02.03	5V Regulator Demand & Feedback Amps Schematic	
91-161-002/A4	1	в	27.02.03	MCU, Reset & Clock EEPROM, A/D, LEDs Schematic	
91-162-001/A4	1	в	27.02.03	11.1V Regulators & Signal Circuits Schematic	
91-162-002/A4	1	в	27.02.03	Current Controlled Switching Supply Circuit Schematic	
91-162-003/A4	1	в	27.02.03	Positioner Interface Protection Circuits Schematics	
91-168/A3	1	в	12-05-03	Extra Information Label for Inside Lid (Proximity Sensor	Types)
91-176/A3	1	A	12-05-03	Extra Information Label for Inside Lid (Mechanical Lin Types)	uit Switch
91-177/A3	1	Α	12-05-03	External Wiring Label for Inside Lid (Showing Optional M Limit Switches)	lechanical
BAS-CERT-081					lasue 1
C.S. 22.06.23	NE	TR	20L	Trading Estate Farnham Surrey England	Doc. No. TD 120 Page 17 of 25

lssue R



1

8. BASEEFA EC – TYPE EXAMINATION CERTIFICATE – Page 4

Certificate Number Baseefa03ATEX0098X Issue 5				SGS Issued 20 November 2019 Page 4 of 4
Number	Sheet	Issue	Date	Description
91-179/A3	1	Α	12-05-03	External Wiring Label for Inside Lid (Showing Optional Proximity Sensors)
650-098-8 650-098-9/A3	1	в	07-10-03	Switch Assemblies (IS Proximity, Top & Bottom)
52-000-349/A3	1	Α	04.09.13	Monitor with Anti-Static Film (ATEX)
SK3490/A3	1	А	08-02-06	Anti-Static Cap

All the above drawings are common to and held with IECEx BAS 13.0117.

20 Certificate History

Certificate No.	Date	Comments
Baseefa03ATEX0098	16 May 2003	The release of the prime certificate. The associated test and assessment is documented in Test Report No. 02(C)0445.
Baseefa03ATEX0098/1X	10 April 2006	To permit the use of an anti-static position indicator cap and use of the Positioner within combustible dust hazards. The associated test and assessment is documented in Test Report No. 05(C)0767.
Baseefa03ATEX0098 Issue 2	14 December 2011	This issue of the certificate incorporates previously issued primary & supplementary certificates into one certificate and confirms the current design meets the requirements of EN 60079-0: 2009 & EN 60079-11: 2007 (Dust approval is removed) including the revision of the marking in accordance with these standards. Also, minor changes to drawings not affecting the intrinsic safety assessment. Project 11/0873.
Baseefa03ATEX0098 Issue 3	27 February 2014	This issue of the certificate confirms the current design meets the requirements of EN 60079-0: 2012 & EN 60079-11: 2012. Also, minor changes to drawings not affecting the intrinsic safety assessment. IECEx certificate IECEx BAS 13.0117 is issued. The associated test and assessment is documented in IECEx Report GB/BAS/ExTR13.0251/00. Project 13/0757.
Baseefa03ATEX0098 Issue 4	14 April 2015	Minor changes to drawings. This issue of the certificate confirms the current design meets the requirements of EN 60079-0: 2012 + A11: 2013. The associated test and assessment is documented in IECEx Report GB/BAS/ExTR15.0097/00. Project 13/0757.
Baseefa03ATEX0098X Issue 5	20 November 2019	Minor changes to label drawing. Alternative enclosure material Aluminium which introduces an 'X' condition regarding protection against impact and abrasion when located in a zone 0. The associated test and assessment is documented in IECEx Report GB/BAS/ExTR19.0317/00. Project 19/0569.

BAS-CERT-081

Issue 1

C.S.

22.06.23

Issue

R

Trading Estate Farnham Surrey England

Doc. No. TD 120 Page 18 of 25

KINETROL



	IECEx	IECEx Certificate of Conformity	•
	INTERNATIONAL E IEC Certification S for rules and detai	ELECTROTECHNICAL COMMISSION System for Explosive Atmospheres is of the IECEx Scheme visit www.iecex.com	
Certificate No.:	IECEx BAS 13.0117X	Page 1 of 4	Certificate history:
Status:	Current	Issue No: 2	Issue 0 (2014-02-27)
Date of Issue:	2019-11-21		
Applicant:	Kinetrol Limited Trading Estate Farnham Surrey GU9 9NU United Kingdom		
Equipment:	EL Electropneumatic Positioner		
Optional accessory:			
Type of Protection:	Intrinsic Safety		
Marking:	Ex ia IIC T4 Ga		
Approved for issue of	n behalf of the IECEx	R S Sinclair	
Approved for issue of Certification Body:	n behalf of the IECEx	R S Sinclair	
Approved for issue o Certification Body: Position: Signature: (for printed version)	n behalf of the IECEx	R S Sinclair Technical Manager R S S J J	~~~
Approved for issue of Certification Body: Position: Signature: (for printed version) Date:	n behalf of the IECEx	R S Sinclair Technical Manager RSSA	~~~
Approved for issue of Certification Body: Position: Signature: (for printed version) Date: 1. This certificate ar 2. This certificate is 3. The Status and a Certificate issued SGS Baseefa Lin	n behalf of the IECEx nd schedule may only be reproduced not transferable and remains the pro uthenticity of this certificate may be v	R S Sinclair Technical Manager R S Sinclair R S Sinclair Manager Manag	ode.
Approved for issue of Certification Body: Position: Signature: (for printed version) Date: 1. This certificate ar 2. This certificate is 3. The Status and a Certificate issued SGS Baseefa Lin Rockhead Busin Staden Lane Buxton, Derbyst United Kingdom	n behalf of the IECEx nd schedule may only be reproduced not transferable and remains the pro uthenticity of this certificate may be v l by: mited ness Park hire, SK17 9RZ	R S Sinclair Technical Manager A.M.M.J. M.M.M.J. M.	ode.



8. IECEX CERTIFICATE OF CONFORMITY - Page 2

IEC [®]		of C	onformity	
Certificate No.:	IECEX BAS 13.0117X		Page 2 of 4	
Date of issue:	2019-11-21		Issue No: 2	
Manufacturer:	Kinetrol Limited Trading Estate Famham Surrey GU9 9NU United Kingdom			
Additional manufacturing locations:				
This certificate is issu the IEC Standard list assessed and found IECEx Scheme Rules	ued as verification that a sample below and that the manufacture to comply with the IECEx Qualit s, IECEx 02 and Operational Do	e(s), representative of produc er's quality system, relating t ty system requirements. This ocuments as amended	ction, was assessed and tested and found to co o the Ex products covered by this certificate, wa certificate is granted subject to the conditions a	mply with 15 Is set out i
STANDARDS : The equipment and a to comply with the fol	iny acceptable variations to it sp lowing standards	pecified in the schedule of th	is certificate and the identified documents, was	found
IEC 60079-0:2011 Edition:6.0	Explosive atmospheres - Part	0: General requirements		
IEC 60079-11:2011 Edition:6.0	Explosive atmospheres - Part	11: Equipment protection by	v intrinsic safety "i"	
	This Certificate does not in other than those	dicate compliance with safe expressly included in the S	ty and performance requirements tandards listed above.	
TEST & ASSESSME A sample(s) of the eq	NT REPORTS: upment listed has successfully	met the examination and te	st requirements as recorded in:	
Test Reports:				
GB/BAS/ExTR13.025	51/00 GB/BAS	S/ExTR15.0097/00	GB/BAS/ExTR19.0317/00	
Quality Assessment F	Report:			
GB/SIR/QAR07.0011	<i>J</i> 07			



8. IECEx CERTIFICATE OF CONFORMITY – Pages 3 & 4

	IECEX	IECEx Certificate of Conformity	
Certificate No.:	IECEX BAS 13.0117X	Page 3 of 4	
Date of issue:	2019-11-21	Issue No: 2	
EQUIPMENT: Equipment and sy	stems covered by this Certificate are a	as follows:	
The EL Electrophe there until the input	eumatic Positioner is designed to drive It signal changes. The enclosure may l	a rotary or linear actuator to a position set by a 4 – 20 mA input signa be zinc alloy or aluminium alloy which introduces a specific condition of	II and hold it of use.
The apparatus cor signal and an optic positioner signal lo feedback potention N Type 1 inductive electrically isolated	mprises a microprocessor based digita onal angle retransmit circuit which prov oop. The circuits are mounted on two P meter and the servo valve. There are a e proximity switches to Certificate No. P d from the input and feedback signals.	I positioner circuit which controls a servo valve according to the 4- vides a linear 4-20mA feedback signal which is electrically isolated fro CBs which are located inside the positioner enclosure together with th also two optional limit switches (either micro-switches or Pepperl & Fu PTB00ATEX2032X) which form two separate intrinsically safe circuits	- 20 mA input m the he position chs NJ 2-V3- which are
External electrical	connections are made via separate te	rminal blocks inside the positioner enclosure.	
Input Parameters	- see Annex.		
SPECIFIC CONDI 1. The EL Positior taken to protect it t	TIONS OF USE: YES as shown belo ner enclosure may be made from alum from impact or abrasion if located in a	w: inium alloy and given a protective epoxy paint finish; however, care sl zone 0 area.	hould be
150	TEAL	IECEx Cortificato	
		IECEx Certificate of Conformity	
Certificate No.:	IECEX BAS 13.0117X	IECEx Certificate of Conformity Page 4 of 4	
Certificate No.: Date of issue:	IECEX BAS 13.0117X 2019-11-21	IECEx Certificate of Conformity Page 4 of 4 Issue No: 2	
Certificate No.: Date of issue:	IECEX BAS 13.0117X 2019-11-21	IECEx Certificate of Conformity Page 4 of 4 Issue No: 2	
Certificate No.: Date of issue: DETAILS OF CER Minor changes to the	IECEX BAS 13.0117X 2019-11-21 RTIFICATE CHANGES (for issues 1 at the label and an alternative enclosure	IECEX Certificate of Conformity Page 4 of 4 Issue No: 2 and above) material which has introduced a specific condition of use.	
Certificate No.: Date of issue: DETAILS OF CER Minor changes to the ExTR: GB/BAS	IECEX BAS 13.0117X 2019-11-21 RTIFICATE CHANGES (for issues 1 a the label and an alternative enclosure S/EXTR19.0317/00	IECEX Certificate of Conformity Page 4 of 4 Issue No: 2 and above) material which has introduced a specific condition of use.	
Certificate No.: Date of issue: DETAILS OF CER Minor changes to the ExTR: GB/BAS	IECEX BAS 13.0117X 2019-11-21 RTIFICATE CHANGES (for issues 1 a the label and an alternative enclosure S/ExTR19.0317/00	IECEX Certificate of Conformity Page 4 of 4 Issue No: 2 Ind above material which has introduced a specific condition of use.	
Certificate No.: Date of issue: DETAILS OF CER Minor changes to the ExTR: GB/BAS Annex: IECEX BAS 13.011	IECEX BAS 13.0117X 2019-11-21 RTIFICATE CHANGES (for issues 1 a the label and an alternative enclosure S/ExTR19.0317/00	IECEX Certificate of Conformity Page 4 of 4 Issue No: 2 Ind above material which has introduced a specific condition of use.	
Certificate No.: Date of issue: DETAILS OF CER Minor changes to the ExTR: GB/BAS Annex: IECEX BAS 13.011	IECEX BAS 13.0117X 2019-11-21 RTIFICATE CHANGES (for issues 1 a the label and an alternative enclosure S/ExTR19.0317/00	IECEX Certificate of Conformity Page 4 of 4 Issue No: 2 Ind above) material which has introduced a specific condition of use. File Reference: 19/0569	
Certificate No.: Date of issue: DETAILS OF CER Minor changes to the ExTR: GB/BAS Annex: IECEX BAS 13.013	IECEX BAS 13.0117X 2019-11-21 RTIFICATE CHANGES (for issues 1 a the label and an alternative enclosure S/ExTR19.0317/00	IECEEX Certificate of Conformity Page 4 of 4 Issue No: 2 Ind above material which has introduced a specific condition of use. File Reference: 19/0569	
Certificate No.: Date of issue: DETAILS OF CEF Minor changes to the ExTR: GB/BAS Annex: IECEX BAS 13.013	IECEX BAS 13.0117X 2019-11-21 RTIFICATE CHANGES (for issues 1 a the label and an alternative enclosure S/ExTR19.0317/00	IECEEX Certificate of Conformation Page 4 of 4 Issue No: 2 Ind above material which has introduced a specific condition of use. File Reference: 19/0569	
Certificate No.: Date of issue: DETAILS OF CER Minor changes to I ExTR: GB/BAS Annex: IECEX BAS 13.01	IECEX BAS 13.0117X 2019-11-21 RTIFICATE CHANGES (for issues 1 a the label and an alternative enclosure S/ExTR19.0317/00	IECEEX Certificate of Conformity Page 4 of 4 Issue No: 2 Ind above) material which has introduced a specific condition of use. File Reference: 19/05/69	



8. IECEX CERTIFICATE OF CONFORMITY – ANNEX.

SGS Baseefa Limited Rockhead Business Park Staden lane, Buxton, Derbyshire SK17 9RZ United Kingdom	SGS
ANNEX to IECEx BAS 13.0117 Issue No. 1	Date: 2019/11/20

Input parameters:

4 - 20mA Signal:

Ui Ii Pi	=	28V 93.3mA 0.653W	Ci Li	=	0 0	or	Ui Ii Pi	= =	25.2V 100mA 0.63W	Ci Li	=	0
Ang	gle F	Retransmit c	ircuit:									
U	=	28V	Ci	=	0	or	Ui	=	25.2V	Ci	=	0
h.	=	93.3mA	L	=	0		h.	=	100mA	L	=	0
Pi	=	0.653W					Pi	=	0.63W			

Limit Switches (micro-switches):

Ui	=	28V	Ci	=	0
li -	=	93.3mA	Li	=	0
Pi	=	0.653W			

Limit Switches (Pepperl & Fuchs NJ 2-V3-N Inductive Proximity switches to Certificate No. PTB00ATEX2032X)

Ui	=	16V	Ci	=	40nF
h	=	25mA	L	=	50µH
Pi	=	64mW			

Page 1 of 1

Trading Estate Farnham Surrey England

Doc. No. TD 120

Page 22 of 25

Issue	C.S.	Π ក្រាលា ចេ ៣៣ ចេ Λ Π
R	22.06.23	╨ℤҴѾӏ҈ҪҴҠѾѾ



9. SPARE PARTS





9.2 EL POSITIONER SPARE PART LIST

EL Positioner Spares List – isafe

17/11/16

Model 05 EL for use on 05 Actuators Only

Model 07 EL for use with 07 to 15 Actuators

05 Discrete EL for use with 16 to 30 Actuators or as NAMUR Discrete Positioners

Note – ASP spares codes are for ANSI versions CW = Clockwise and CCW = Counter Clockwise

ITEM	DESCRIPTION	QTY	Model 05 EL	Model 07 EL	Discrete EL
1	EL POSITIONER BODY MACHINED	1	N/A	N/A	N/A
2	CHANNEL PLATE GASKET	1	SP975	SP975	SP975
3	CHANNEL PLATE	1	SP946	SP950	SP951
		1	ASP946	ASP950	ASP951
4	M3 x 8 SOCKET HEADED CAP SCREW	21	SP975	SP975	SP975
5	O'RING 158ID x 1.78 SECTION	1	SP975	SP975	SP975
6	EL POSITIONER LID	1	SP980 – CCW	SP980 – CCW	SP980 – CCW
		OR	SP981 – CW	SP981 – CW	SP981 – CW
		OR	ASP980 – CCW	ASP980 – CCW	ASP980 – CCW
		OR	ASP981 – CW	ASP981 – CW	ASP981 – CW
7	SERVO VALVE ASSEMBLY	1	SP942	SP942	SP942
8	DIVERTER GASKET	1	SP975	SP975	SP975
9	DIVERTER BLOCK	1	SP963	SP963	SP963
10	CARRIER PLATE ASSEMBLY		CONTACT KINETROL FOR ISAFE VERSIONS		
11	M5 EARTH TERMINAL	1	SP977	SP977	SP977
12	CLEAR CONE MONITOR	1	CONTACT	CONTACT	CONTACT
			KINETROL	KINETROL	KINETROL
13	SELF TAPPING SCREWS	2	See Item 12	See Item 12	See Item 12
14	SCREW MODIFIED	4	See Item 6	See Item 6	See Item 6
15	NYLON WASHER	4	See Item 6	See Item 6	See Item 6
16	SHAFT SEAL	1	SP975	SP975	SP975
17	EL POSITIONER LABEL	1	N/A	N/A	N/A
18	M4 EARTH TERMINAL	1	SP976	SP976	SP976
20	NEEDLE VALVE	2	SP729	SP729	SP729
22	SILENCER	1	SP975	SP975	SP975
23	SILENCER PLATE	1	SP956	SP956	SP956
24	6 x ¼ SELF TAPPING SCREW	2	SP975	SP975	SP975
26	FILTER	1	SP975	SP975	SP975
27	G 1/8 RED CAP – PUSH IN	1	SP992	SP992	SP992



9.2 SF	PARE PART L	IST CONTINUED.				
28	TOP GASK	ET	1	SP975	SP975	SP975
31	O'RING 26.	70 ID x 1.78 SECTION	1	SP975	SP975	SP975
33	CARRIER F	PLATE	1	See Item 10	See Item 10	See Item 10
34	TERMINAL	BLOCK 3/2	1	SP1003	SP1003	SP1003
35	POTENTION	METER CLAMP STRAP	1	SP975	SP975	SP975
37	FOLLOWER	RWHEEL	1	SP1005	SP1005	SP1005
39	POTENTION	METER ENERGISER SPRING	1	See item 41	See item 41	See item 41
40	POTENTIO	METER SPRING MANDRELL	1	See item 41	See Item 41	See Item 41
41	POTENTION	METER 20K	1	SP932	SP932	SP932
42	M2.5 x 8 SI	OTTED CHEESE HEAD SCREW	2	See item 41	See item 41	See item 41
45	INDICATOR	ASSEMBLY	1	SP940	SP940	SP940
46	TOP / BOT	FOM SWITCH & WIRES	1	CONTACT KINE	TROL FOR ISAFE	EVERSIONS
48	LIMIT SWIT	CH COVER	1	See Item 46	See Item 46	See Item 46
49	M3 x 25 SL	OTTED CHEESE HEAD SCREW	2	See Item 46	See Item 46	See Item 46
51	DIGITAL PC	B COVER	1	SP1008	SP1008	SP1008
52	DIGITAL PC	B ASSEMBLY	1	SP1007	SP1007	SP1007
54	4 WAY TEF	RMINAL BLOCK	1	SP1002	SP1002	SP1002
55	TERMINAL	BLOCK 3/3	1 OR 2	SP1004 (x1)	SP1004 (x1)	SP1004 (x1)
56	M3 SPACE	R	2	See Item 10	See Item 10	See Item 10
100	POSITIONE	RINDICATOR	1	See Item 45	See Item 45	See Item 45
101	M3 FULL N	UT	1	See Item 45	See Item 45	See Item 45
102	M3 x 10 SL	OTTED CHEESE HEAD SCREW	1	See Item 45	See Item 45	See Item 45
103	SERVO VA	LVE BASE GASKET	1	SP975	SP975	SP975
105	M3 x 6 SLC	TTED CHEESE HEAD SCREW	1	SP975	SP975	SP975
106	PLASTIC C	OUPLING ASSEMBLY	1	SP965	SP988	SP965
						also see item 119 or 120
107	COLLET		1	See Item 106	See Item 106	See Item 106
108	M5 THIN NU	Л	1	See Item 106	See Item 106	See Item 106
109	6 x ¼ SELF	TAPPING SCREW	1	See Item 106	See Item 106	See Item 106
110	BOTTOM S	TRIKER	1	See Item 106	See Item 106	See Item 106
111	LEE SPRIN	G	1	See Item 106	See Item 106	See Item 106
112	TOP STRIK	ER	1	See Item 106	See Item 106	See Item 106
113	O'RING 22.2	L x 1.6 SECTION	1	See Item 106	See Item 106	See Item 106
114	POSITIONE	R SECURING RING	1	SP962	SP962	SP962
				Or see item 106	Or see item 106	Or see item 106
115	M5 PLAIN V	VASHER	1	See Item 106	See Item 106	See Item 106
116	5MM BELLI	EVILLE WASHER	2	See Item 106	See Item 106	See Item 106
117	M5 x 25 SC	REW	1	See Item 106	See Item 106	See Item 106
118	COVER PL	UG	1	See Item 106	See Item 106	See Item 106
119	05 DISCRE	TE SQUARE ADAPTOR	1	N/A	N/A	SP1601
120	NAMUR DIS	SCRETE COUPLING ADAPTOR	1	N/A	N/A	SP1603
121	O'RING		1	SP975	SP975	SP975
ssue R	C.S. 22.06.23	KINETROL	Trading Est	ate Farnham Su	Irrey England	Doc. No. TD 12 Page 25 of 2